



SUBJECT

CP2000 – Loading data from Card

EFFECTIVE DATE

May 9, 2006

S.O.P. NUMBER

HEI0003

DATE REVISED

May 9, 2006

PAGE

1

OF

2


Standard Operating Procedure

This procedure outlines the steps involved in loading data from the On-Line Communications Module into the Heidelberg CP2000 console.


1. Go to the Job Preparation Screen by pressing



2. Press the 'Load Inking Unit Settings' button




3. The following window will appear:




Note: Make sure that it says 'Job Memory Card' in the lower left hand corner; if not – press the




button and select the Job Memory Card option.




4. Select the Job from Position 1 and press the  button. This will load the data into memory.

STANDARD OPERATING PROCEDURE

5. To release the data to the ink keys, press the  button.

6. The following window will appear:



7. Ensure that both   options are enabled and then press the  button to send the information to the ink keys.

PREPARED BY:

DATE:

APPROVED BY:

DATE: