



Standard Operating Procedure

SUBJECT

Calibrating the RS400 Scanner

EFFECTIVE DATE

Jan 8, 2004

S.O.P. NUMBER

CAL0002

DATE REVISED

Jan 8, 2004

PAGE

1

OF

1

1. If ColorLinx is not running, Start the application by double-clicking on the ColorLinx Icon located on the desktop.
2. Press the Calibrate button which is located on the Toolbar.
3. Enter the values from your Calibration card into the corresponding spaces in the ColorLinx software.
4. Position the aperture of the RS400 on the White block of the calibration card. Press and hold the Green button on the scanner to Calibrate to Paper White.
5. Take a spot reading on each of the KCMY patches by positioning the unit on the appropriate patch and then pressing the Green scanner button once.
6. Press the OK button on the Calibrate window.
7. Position the scanner on the White Patch that is located on the Black Calibration Plaque.
8. Press and hold the Green scanner button.
9. After the scanner beeps twice the calibration is complete**. You can now remove the scanner from the Calibration Plaque and use it to take spot readings or perform scans.

**Note: do not remove the scanner from the Black Calibration Plaque until you hear the two beeps.

Note:

- Holding the Green scanner button will calibrate the unit to whatever is under the aperture
- Pressing the button once will take a spot measurement
- Press the button twice will activate the scan mode