



Standard Operating Procedure

SUBJECT

Intellitrax Track Alignment

EFFECTIVE DATE

Jan 3, 2008

S.O.P. NUMBER

ITX001

DATE REVISED

Jan 3, 2008

PAGE

1

OF

1

The Intellitrax Track Alignment procedure can be completed with ColorLinx running or shut down.

1. Place the Intellitrax Track Alignment Reference Card on the scanning track 3" away from the Head.
2. Hold the back edge of the card so that it doesn't move.
3. On the computer, select *Run* from the Windows *Start* menu.
4. Type '*telnet*' and press the *OK* button.
5. Type '*open 172.16.1.100*' and then press the *Enter* key.
6. Type '*cp*' and then press the *Enter* key.
7. Once the Track Alignment is complete, exit the telnet program by:
 - a. typing in '*exit*' and pressing the *Enter* key
 - b. pressing the '*Space Bar*'
 - c. typing in '*quit*' and pressing the *Enter* key